



Pure Shower Genius

Handset Showerhead Fitting Instructions

Oxygenics aerated showerheads typically reduce water consumption by 50% but savings of up to 75% can be expected. The primary function of an Oxygenics showerhead is to reduce water consumption. The increase flow and pressure comes through our patented technology. Oxygenics Showerheads are designed to work on systems over 1.5 BAR of pressure. Gravity fed system usually operate below 1.0 Bar and are not suitable for Oxygenics Showerhead.

If you are in doubt as to the pressure or the type of system you have please review the information below or contact your plumber before purchasing an Oxygenics showerhead,

Step 1

Remove your existing Showerhead from the Hose.

To remove, hold the hose in one hand and turn the showerhead in a counterclockwise direction.

Step 2

Make Sure the Hose is clean and clear. Take care not to lose any washers. Remove any dirt or debris. Flush out the hose for 5-10 seconds.

Step 3

Screw your new Oxygenics Handset into place in a clockwise direction, hand tighten only.

