



Pure Shower Genius

Fixed Showerhead Fitting Instructions


Oxygenics aerated showerheads typically reduce water consumption by 50% but savings of up to 75% can be expected. The primary function of an Oxygenics showerhead is to reduce water consumption. The increase flow and pressure comes through our patented technology. Oxygenics Showerheads are designed to work on systems over 1.5 BAR of pressure. Gravity fed system usually operate below 1.0 Bar and are not suitable for Oxygenics Showerhead.

If you are in doubt as to the pressure or the type of system you have please review the information below or contact your plumber before purchasing an Oxygenics showerhead,




STEP 1

Remove your existing shower head. To remove, turn the existing shower head in a counterclockwise direction.




STEP 2

Remove any remnants of old plumber's tape and flush out shower pipe for 5 to 10 seconds.



STEP 3

Wrap plumber's tape clockwise 3 or 4 turns around threaded end of shower arm.



STEP 4

In a clockwise direction, screw your new shower head onto the taped portion of the shower arm. Hand tighten only.

